LOW PRESSURE EXHAUST FANS
LPEV SERIES
12,16, & 22 INCH SIZES WITH VENTURI FRAME

READ AND SAVE THESE INSTRUCTIONS

- LPEV fans are intended to be directly wired. All wiring must be done by a qualified electrician. DO NOT use an extension cord with these fans.
- DO NOT place foreign objects through the guard into blade. Never attempt to stop the fan blades when fan is in operation.
- ALWAYS turn off the fan to clean.
- Marley Engineered Products assumes no liability resulting from the improper use or installation of this product.
- Marley Engineered Products reserves the right to make any changes and improvements in its products at any time without notice

INSTALLATION

- LPEV fans require four screws to hold them firmly in place.
- LPEV fans feature a speed presetting air flow selector switch which allows user to select desired amount of air and velocity.
- BE SURE all electrical power is off before wiring.
- For single-speed operation:
  1. Preset a desired speed.
  2. Remove the junction box cover.
  3. Connect wire in the junction box. The grounding wire should be connected to any screw on the junction box.
  4. Replace the junction box cover.

  For variable speed operation:
  1. Preset high speed.
  2. Use Marley Engineered Products solid state fan speed controller (Model: SS-2) and install it per the instructions.
  3. Repeat procedures 2,3, and 4 above for single-speed operation. NOTE: GROUND IN ACCORDANCE WITH STATE AND LOCAL CODES.
- It is normal for the motor to feel warm to the touch during operation. The motor is thermally protected and will automatically shut off should it overheat for any reason. The fan will automatically turn on once the motor has cooled.
- The motor bearings are permanently lubricated at the factory and do not require any lubrication.

CLEANING

- Use a damp rag and mild detergent to clean the blade and guard. Always turn fan off before attempting to clean.

LOW PRESSURE EXHAUST FANS
LPE AND LPES
12, 16, 24, 30

READ AND SAVE THESE INSTRUCTIONS

- LPE series fans are intended to be directly wired. All wiring must be done by a qualified electrician. DO NOT use an extension cord with these fans.
- DO NOT place foreign objects through the guard into blade. Never attempt to stop the fan blades when fan is in operation.
- ALWAYS turn off the fan to clean.
- Marley Engineered Products assumes no liability resulting from the improper use or installation of this product.
- Marley Engineered Products reserves the right to make any changes and improvements in its products at any time without notice

INSTALLATION

- LPE fans require four screws to mount unit firmly to desired mounting surface; eight screws are required for the LPE-30. Mounting screws are not provided.
- LPES MODELS are provided with hardware for mounting the LPE unit to the shutter. The mounting hardware to mount the LPES unit to its desired mounting surface is not provided
- Both LPE and LPES fans feature a speed presetting air flow selector switch which allows user to select desired amount of air and velocity.
- Disconnect all electrical power before performing any wiring. All wiring should be done by a qualified electrician.
- For single-speed operation:
  1. Preset a desired speed.
  2. Remove the junction box cover.
  3. Connect wire in the junction box. The grounding wire should be connected to any screw on the junction box.
  4. Replace the junction box cover.

  For variable speed operation:
  1. Preset high speed.
  2. Use Marley Engineered Products solid state fan speed controller (Model: SS-2) and install it per the instructions.
  3. Repeat procedures 2,3, and 4 above for single-speed operation. NOTE: GROUND IN ACCORDANCE WITH STATE AND LOCAL CODES.
- It is normal for the motor to feel warm to the touch during operation. The motor is thermally protected and will automatically shut off should it overheat for any reason. The fan will automatically turn on once the motor has cooled.
- The motor bearings are permanently lubricated at the factory and do not require any lubrication.
- Wall Openings Required:

Model	Opening
LPE-12	12.5” Diameter Circle or 12.5”x12.5” Square
LPE-16	16.5” Diameter Circle or 16.5”x16.5” Square
LPE-24	24.5” Diameter Circle or 24.5”x24.5” Square
LPE-30	30.5” Diameter Circle or 30.5”x30.5” Square

Model	Opening
LPE-12S	12.5”x12.5” Square
LPE-16S	16.5”x16.5” Square
LPE-24S	24.5”x24.5” Square
LPE-30S	30.5”x30.5” Square

LIMITED WARRANTY

Dear Customer,

Thank you for your interest in Marley Engineered Products products. We're sure you will enjoy its benefits for many years to come. Please take a minute to fill out the following information and keep it in your permanent records.

Date Purchased _____ Date Installed _____

Model Number _____

LIMITED WARRANTY

This Marley Engineered Products product is warranted to be free of defects in material and workmanship for 12 months from date of original purchase.

There is no other warranty, express or implied, except such as is expressly set forth herein. Seller will not be liable for any general, consequential, or incidental damages, including without limitation any damages for loss of use or loss of profits, for any breach of warranty or for negligence. Seller's liability and buyer's exclusive remedy are limited to the repair of defective goods or the shipment of equivalent goods, or the granting of a reasonable allowance on account of any defects, as the seller may elect.

To obtain performance under this warranty, you must:

1. Contact the Marley Engineered Products Service Department at 1-800-683-0062 between the hours of 8:00 a.m. and 5:00 p.m. E.S.T. Monday through Friday.

2. Provide the model number of the product, the date of installation, and state the nature of the difficulty being experienced.

3. The Marley Engineered Products Service Representative will determine the best way to resolve the difficulty.

Products within warranty which have been installed and returned to the seller for repair will be repaired and returned as used products. Repairs to products outside the warranty period will be subject to labor and parts charges.

Some states have enacted legislation which (a) does not allow the inclusion of limitations on incidental or consequential damages; (b) does not allow limitations on the length of a warranty period; (c) precludes exclusion, during the period of a limited warranty, of any implied warranties of merchantability or fitness for purpose.

To the extent of such provisions being applicable in your state, the limitations in this warranty may not apply.

TO ENSURE SAFE OPERATION

- Be sure that this unit is correctly installed and wired by a qualified installer in accordance with the instructions and applicable NEC or equivalent codes.
- Be sure that operating instructions are followed and that moving and heating parts are kept clean and free from obstructions.

Any warranties granted or liabilities assumed hereunder will not apply to goods that have been damaged in transit, altered, repaired, installed or operated otherwise than in conformity with the above requirements for safe operation.

HOW TO ORDER REPAIR PARTS

In order to obtain any needed repair or replacement parts, warranty service or technical information, please contact Marley Engineered Products Service Center toll-free by calling 1-800-642-HEAT.

When ordering repair parts, always give the information listed as follows:

1. The Part Number
2. The Model Number
3. The Part Description
4. Date of Manufacture

Part No. 5200-2575-000
PPD-035
5-00



470 Beauty Spot Rd. East
Bennettsville, SC 29512 USA